



Control Panel Instruction Manual


MK117



- | | |
|------------------------|--------------------------|
| ① ----- ON/OFF Power | ⑨ ----- Manual |
| ② ----- Display screen | ⑩ ----- Warning button |
| ③ ----- Steam | ⑪ ----- Remote reception |
| ④ ----- Light control | ⑫ ----- Fan |
| ⑤ ----- FM/CD on/off | ⑬ ----- Ozoner |
| ⑥ ----- Telephone | ⑭ ----- Increase Key |
| ⑦ ----- FM | ⑮ ----- Key Unlocking |
| ⑧ ----- Decrease Key | ⑯ ----- MIC |



- | | |
|-----------------------------|--------------------------|
| ① ----- Temperature | ⑧ ----- Ozoner |
| ② ----- Temperature setting | ⑨ ----- Telephone |
| ③ ----- Time setting | ⑩ ----- FM tuner |
| ④ ----- Radio | ⑪ ----- FM tuner setting |
| ⑤ ----- CD | ⑫ ----- Locked mark |
| ⑥ ----- Lack of water | ⑬ ----- Fan |
| ⑦ ----- Steam | ⑭ ----- Light |



Remote

① ----- Power ON/OFF & Unlock	⑦ ----- Steam
② ----- Fan ON/OFF	⑧ -----Light ON/OFF
③ ----- FM Tuner Plus Key	⑨ -----Steam
④ ----- Decrease	⑩ ----- Increase
⑤ ----- FM/CD	⑪ ----- Telephone
⑥ ----- Volume Decrease	⑫ -----Volume Increase

Control Panel Operation Instructions

1. power on/off

When system on standby state, press this key(2 seconds or more),then display on, simultaneously lights on;Press key again,system off(if no any further operation in 1hour,system auto-off);When system off,touch the panel anywhere,key light will turn on,but it will be off in 5 seconds if no power on.

2. Ozoner

When system on, press the panel key, ozone function will be turn on; then touch it once again,ozoner closes;and the same time,fan and light will be on.

3. Fan

When system on,touch the panel key,fan will work on;then touch it once again,fan function closes;the same time there will be fan mark on/off in display.

4. light

When system on,firstly touch the panel key,top light will be off/background light on;touch once again the key,top light and background light turn on;third touch this key,top/background light off.

5. FM/CD

When system on,firstly touch the panel key,radio function on;and radio tuner display on;then touch its key again,radio function switch into CD;and CD mark will show in display;and touch it once again,CD function shut off.

6. Radio tuner searching(radio on work)



①、Auto-search/store:press key for 2 secs or more,auto-search/store function on,tuner range from 87.5-108.0MHZ(fixed tuner quantity 1-32 available,it depends on signal situation).

②. Man-search/store: touch **TUN** key, tuner will start flashing, press key  

to choose the one you like more, then touch the key **TUN**, store the new tuner


(add new tuner into prefer-list).

③. Tuner switch: press key  /  to increase/decrease the tuner.

④. Volume adjustment: **TUN** press this key, and press key  /  to adjust the

voice volume (range from 0-15DB).


7. Steam



When system on, press the key  to start steam function, steam mark will


be on; (temperature set at 45 degrees and the time set at 45 minutes by default)

When lack of water, that mark flashes and steam shut off.




8. Telephone




When calling comes, speaker stops work pausely, press  key to answer

it, and tel mark stop flashing; when calling, you could adjust  /  to choose



right volume; and press key  again, phone off and speaker will be on.

8. Steam adjustment

①. steam time adjusting: key  to choose time, then press   key to increase steam time (range from 1-99mins).


②. steam temperature: press  to choose temperature, key  /  to raise/lower the temperature (range from 20-60°C).

10. Unlocking

If there is no any further operation on touch panel in 20secs, system will be locked auto, mark  will flashes, press  key for 2 secs or

more to unlock panel, then all of keys active on.

11. Warning

When system on, press key  to open warning function, the same time

light and fan are all starting working; touch it again to shut it off.

Working Conditions and Property				
<i>Voltage Rating:</i>	AC 220 V	<i>Normal Frequency:</i>	50Hz~60Hz	
<i>Rated Current:</i>	13.6A	<i>Power Rating:</i>	2860W	
<i>Insulating Resistance:</i>	> 20 M	<i>Drain Current:</i>	<i>Measured upto enterprise safety standard</i>	
<i>Waterproof Grade:</i>	IPX5	<i>Leak Protection:</i>	(15 ~ 30)mA	
Load Configuration Parameters				
LOAD TYPE	RATED LOAD VOLTAGE	RATED LOAD FREQUENCY	RATED OPERATING POWER	QUANTITY
Steam	Ac220 V	50Hz/60Hz	2.8kW	1
Top Light	Ac12 V	50Hz/60Hz	32W	1
Exhaust	Dc12 V	—	4W	1
Electromagnetic Valve	Dc12 V	—	5W	2
Speaker	—	—	8 Ω /10W	1-2
Background Light	Ac12 V	50Hz/60Hz	4W	
Ozone Sterilizer	Ac12 V	50Hz/60Hz	5W	1

Due to a policy of continuous improvement the manufacturer reserves the right to change the specification without prior notice